


# HOME DECORATORS C O L L E C T I O N

BF-25146 OPEN WALL MOUNTED STORAGE 28"H×21"W×8"D

INV#16064













## ASSEMBLY INSTRUCTIONS














Made In China



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have came loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.



**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  LEFT SIDE PANEL-1PC	<b>C</b>  RIGHT SIDE PANEL-1PC
<b>D</b>  ADORNING PANEL-1PC	<b>E</b>  STAND PANELS-2PCS	<b>F</b>  ACROSS PANEL-1PC
<b>G</b>  STAND PANELS-2PCS	<b>H</b>  ACROSS PANEL-1PC	<b>I</b>  STAND PANELS-2PCS
<b>J</b>  BOTTOM PANEL-1PC	<b>K</b>  CIRCINAL IRONS-1PC	<b>L</b>  BACK PANEL-1PC

<b>M</b>  <p>CAM-TOOL-1PC 7mm × 5/8"</p>	<b>N</b>  <p>CAM-BOLTS-16PCS</p>	<b>O</b>  <p>CAM-LOCKS-16PCS</p>
<b>P</b>  <p>SCREWS-18PCS 6mm × 5/8"</p>	<b>Q</b>  <p>CAM-LOCK CAPS-4PCS</p>	<b>R</b>  <p>DOWELS-24PCS</p>
<b>S</b>  <p>SCREWS-5PCS 8mm × 1-1/2"</p>	<b>T</b>  <p>SHEET IRONS-2PCS 8mm × 1"</p>	<b>U</b>  <p>GECKOS-5PCS</p>
<b>V</b>  <p>SCREWS-5PCS 8mm × 1-1/4"</p>	<b>W</b>  <p>SCREWS-3PCS</p>	<b>X</b>  <p>EVA PADS-2PCS</p>
<b>Y</b>  <p>SCREWS-8PCS</p>		




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE BOTTOM PANEL(J).

- INSERT 4 DOWELS(R) INTO THE HOLES IN THE STAND PANELS(I).
- ATTACH THE STAND PANELS(I) TO PANEL(J) USING 4 SCREWS(Y).




2). ASSEMBLE THE ACROSS PANEL(H).

- INSERT 4 DOWELS(R) INTO THE HOLES IN THE STAND PANELS(I).
- ATTACH THE ACROSS PANEL(H) TO STAND PANELS(I).




3). ASSEMBLE THE STAND PANELS (G).

- INSERT 4 DOWELS (R) INTO THE HOLES IN THE ACROSS PANEL (H).
- ATTACH THE STAND PANELS (G) TO ACROSS PANEL (H).




4). ASSEMBLE THE ACROSS PANEL (F).

- INSERT 4 DOWELS (R) INTO THE HOLES IN THE STAND PANELS (G).
- ATTACH THE ACROSS PANEL (F) TO STAND PANELS (G).




5). ASSEMBLE THE LEFT SIDE PANEL(B).

- ROTATE 6 CAM-BOLTS(N) INTO THE HOLES IN THE LEFT SIDE PANEL(B).
- PLACE CAM-BOLTS(N) INTO THE HOLES IN THE PANEL(J/H/F) AND ATTACH USING 6 CAM-LOCKS(O).




6). ASSEMBLE THE RIGHT SIDE PANEL(C).

- ROTATE 6 CAM-BOLTS(N) INTO THE HOLES IN THE RIGHT SIDE PANEL(C).
- PLACE CAM-BOLTS(N) INTO THE HOLES IN THE PANEL(J/H/F) AND ATTACH USING 6 CAM-LOCKS(O).



7). ASSEMBLE THE STAND PANEL (E).


- INSERT 4 DOWELS (R) INTO THE HOLES IN THE ACROSS PANEL (F).
- ATTACH THE STAND PANELS (E) TO ACROSS PANEL (F).



8). ASSEMBLE THE TOP PANEL (A).


- ROTATE 4 CAM-BOLTS (N) INTO THE HOLES IN THE TOP PANEL (A).
- INSERT 4 DOWELS (R) INTO THE HOLES IN THE PANELS (E).
- PLACE CAM-BOLTS (N) INTO THE HOLES IN THE PANEL (B/C) AND ATTACH USING 4 CAM-LOCKS (O).
- ROTATE 4 SCREWS (Y) INTO THE HOLES IN THE TOP PANEL (A).






9). ASSEMBLE THE ADORNING PANEL (D).

- ATTACH THE ADORNING PANEL(D) TO TO PANEL(A) USING 3 SCREWS(W).




10). ASSEMBLE THE BACK PANEL (L).

- ATTACH THE BACK PANEL(L) USING 18 SCREWS(P).



### 11). ASSEMBLE THE SHEETIRON(T).


- ATTACH THE SHEETIRON(T) TO TOP PANEL (A) USING 5 SCREWS(S).
- ATTACH THE EVA PADS(X) TO SIDE PANEL (B/C).





### 12). ASSEMBLE THE CIRCINAL IRONS(K).

- ATTACH 4 CAM-LOCK CAPS(Q) ONTO THE 4 CAM-LOCKS(O).
- INSERT THE CIRCINAL IRONS(K) INTO THE HOLES IN THE SIDE PANEL (B/C).

WHEN INSTALLED, PLS PUT THE CIRCINAL IRON(K) IN IT FROM THE LEFT SIDE PANEL (B), THEN PUT IT INTO THE RIGHT SIDE PANEL (C). WHEN DISMANTLED, PLS REMOVE THE LEFT SIDE PANEL (C).



wall



### 13). ASSEMBLE THE GECKOS (U).

- DRILL 5 HOLES INTO THE WALL, PLEASE REFER TO THE REAR BACK PANEL' HOLE DISTANCE AND HEIGHT.
- TAP 5 GECKOS (U) INTO THE HOLES ON THE WALL. THEN ROTATE 5 SCREWS (V) INTO THE GECKOS (U).
- HANG THE CABINET ONTO THE SHEETIRONS (T).